


# FISP®

# 10 Pin JTAG Adapter

FISPAD10R



The 10 pin FISP JTAG adapter is used to program the Atmel microcontrollers using a standard 10 pin JTAG interface. See our website for pricing and ordering information




## Specifications

- Dimensions
  - 41mm x 20mm x 10.5mm
- Compatible with
  - FISP-JTAG
- Compatible Devices
  - Atmel AVR JTAG Microcontrollers

## Instructions for use


Plug the black 10 pin **FEMALE** socket into the FISP.

Plug the provided 10-10 pin programming cable into the 10 pin adaptor socket.




## Connections

### FISP



### TARGET



DNC = Do Not Connect

Designed & Manufactured by:

4D Electronics Ltd  
PO Box 13672  
Christchurch 8141  
New Zealand

Phone: +64 3 982 1113  
Fax: +64 3 982 1114  
Web: <http://www.fisp.co.nz>  
E-mail: [sales@fisp.co.nz](mailto:sales@fisp.co.nz)