


FISP®

10 Pin JTAG Adapter

FISPAD10R



The 10 pin FISP JTAG adapter is used to program the Atmel microcontrollers using a standard 10 pin JTAG interface. See our website for pricing and ordering information




Specifications

- Dimensions
 - 41mm x 20mm x 10.5mm
- Compatible with
 - FISP-JTAG
- Compatible Devices
 - Atmel AVR JTAG Microcontrollers

Instructions for use


Plug the black 10 pin **FEMALE** socket into the FISP.

Plug the provided 10-10 pin programming cable into the 10 pin adaptor socket.




Connections

FISP



TARGET



DNC = Do Not Connect

Designed & Manufactured by:

4D Electronics Ltd
PO Box 13672
Christchurch 8141
New Zealand

Phone: +64 3 982 1113
Fax: +64 3 982 1114
Web: <http://www.fisp.co.nz>
E-mail: sales@fisp.co.nz