


# FISP®

## 6 Pin ISP Adapter

FISPAD06R



The 6 pin FISP In System Programming (ISP) adapter is used to program the Atmel micro controllers using the industry standard 6 pin ISP interface. See our website for pricing and ordering information



### Specifications

- Dimensions
  - 41mm x 20mm x 10.5mm
- Compatible with
  - FISP-JTAG
  - FISP-USB-P10
- Compatible Devices
  - Atmel AVR ISP Microcontrollers

### Instructions for use


Plug the black 10 pin **FEMALE** socket into the FISP.

Plug the provided 6-6 pin programming cable into the 6 pin adaptor socket.




### Connections

#### FISP



#### TARGET



DNC = Do Not Connect

Designed & Manufactured by:

4D Electronics Ltd  
PO Box 13672  
Christchurch 8141  
New Zealand

Phone: +64 3 982 1113  
Fax: +64 3 982 1114  
Web: <http://www.fisp.co.nz>  
E-mail: [sales@fisp.co.nz](mailto:sales@fisp.co.nz)